

CLAMPING SYSTEM INSTALLATION INSTRUCTIONS


| Standard Unit Sizes | | |
|---------------------|--------------|---------------|
| Nominal Unit | Cutout Width | Cutout Height |
| 24 x 24 | 23.125 | 23.125 |
| 36 x 24 | 35.125 | 23.125 |
| 48 x 24 | 47.125 | 23.125 |
| 60 x 24 | 59.125 | 23.125 |
| 72 x 24 | 71.125 | 23.125 |

The diffuser is fully assembled from the factory, with the exception of the HEPA filter option. The HEPA filter is shipped separately.


NOTE: These instructions are for clamp mounting to a sealed ceiling.

- Carefully remove the unit from the shipping carton and inspect for damage that may have occurred during shipping. If shipping damage is found, do not install. Call your rep, salesman, or manufacturer to report damage.
- Wipe down unit to remove shipping dust and debris.
- Prepare the ceiling:** Cut a rectangular hole in the desired location 0.875" smaller than the nominal size of the diffuser. If needed, frame the hole with 2x4 wood or equivalent steel studs. Always measure the units to verify dimensions before making cuts.
- Using a flat screw driver, release the face frame by rotating the quarter-turn fasteners counter clock-wise. Unhook the safety cables from the unit. Set the frame aside.
- Raise the unit into the framed opening until the unit is tight against the ceiling. **Ensure** that all clamping mounts are in the install position before installing. (See Page 2 for Example) It is recommended to further support the unit from above using the tabs welded to the plenum.
- Secure the unit in the ceiling by using the clamping system mounts. See page 2 for more details.
- Install duct work as required. Clean installation debris from the unit and surrounding ceiling.
- Using approved caulk, seal the outer perimeter of the diffuser to the ceiling. Also seal around the mounting screws and any other holes made in the diffuser.
- If applicable, install the HEPA filter per the "Removal and Replacement of the HEPA Filter with Gel Seal" section on page 7 of the Critical Environment IOM.
- Wait at least 30 minutes after filter install and ensure there is a positive pressure in the room before performing any challenge leak testing.
- Raise the face frame back in to place, re-attach the safety chains, and secure the quarter-turn fasteners.


CRITICAL ENVIRONMENT LAMINAR FLOW DIFFUSERS & FAN FILTER UNITS



CEILING CUTOUT EXAMPLE



Clamping System
Mounts Typ (8)




AJ Manufacturing

8701 Elmwood Avenue #400
Kansas City, MO 64132
Phone: (816) 231-5522
Fax: (816) 231-8437
www.AJmfg.com


| | | | | |
|---------------------|---|--------------|-----|--------------|
| DRAWN SLG | CATEGORY CLAMPING SYSTEM INSTALLATION INSTRUCTIONS | TAG | QTY | REV # |
| CHKD RH | PRODUCT LAMINAR FLOW DIFFUSERS & FAN FILTER UNITS | DRAWING NAME | | SHT 1/2 |
| APRVD 01/05/2022 | SIZE | | | SCL 1:16 |
| | | | | DO NOT SCALE |

Clamping System Detail


1. Once the unit is raised into the framed opening until tight against the ceiling, use a hex key to turn the clamp mount actuator counter-clockwise until it is tight to the ceiling.
2. Repeat step 1 until all 8 clamp mounts are tight to the ceiling.



STAINLESS STEEL CRITICAL ENVIRONMENT LAMINAR FLOW DIFFUSERS & FAN FILTER UNITS



Install Position



Clamped Position

* CLAMPS CAN BE CUSTOM DESIGNED FOR DIFFERENT CEILING THICKNESSES



AJ Manufacturing

8701 Elmwood Avenue #400
Kansas City, MO 64132
Phone: (816) 231-5522
Fax: (816) 231-8437
www.AJmfg.com

| | | | | |
|---------------------|---|--------------|-----|--------------|
| DRAWN SLG | CATEGORY CLAMPING SYSTEM INSTALLATION INSTRUCTIONS | TAG | QTY | REV # |
| CHKD RH | PRODUCT LAMINAR FLOW DIFFUSERS & FAN FILTER UNITS | DRAWING NAME | | SHT 2/2 |
| APRVD 01/05/2022 | SIZE | | | SCL 1:20 |
| | | | | DO NOT SCALE |